

## RACK MOUNTABLE, CASCADABLE VGA UTP EXTENDED 1x4 SPLITTER WITH 3.5MM AUDIO



1



2



3



4



5




6



7

### Included in the package:



6 brackets

25 screws

2 blank inserts

1 panel

**P/N: R02-SPL-C5E-35A-104B**

### Step-by-step Instruction Manual:

1. Place bracket to the local unit
2. Screw the bracket to the local unit
3. Align local unit to the panel
4. Screw local unit to the panel
5. Attach the VGA & 3.5mm cable to local unit
6. Attach the RJ45 Cable from local to remote Unit
7. Plug the power to local unit